

Opis produktu

1091 U-500

FM-insert with CO2 sensor 230 V



Ogólne informacje

Typ produktu	1091 U-500
Kod zamówieniowy	2CKA001032A0518
Numer EAN	4011395208717
Opis katalogowy	FM-insert with CO2 sensor 230 V
Opis	With display for carbon dioxide, humidity, temperature and air pressure. Setting values: carbon dioxide 800 ppm - 1500 ppm, humidity 40% - 95%. With 2 zero-potential relay contacts. Nominal voltage: 230 V~ Nominal current: 6 A cos ϕ = 1 Without claw fixation. To fit cover plate 6435-xxx.

Installation

Instrukcje i podręczniki	No document needed
Typ montażu	Flush Mounted

Dane techniczne

Arkusze danych, informacja techniczna	No document needed
Typ czujnika	CO2 sensor

Electrical

Napięcie znamionowe (U_r)	230 V
Prąd znamionowy (I_n)	6 A
Rodzaj obciążenia	Inductive load

Design

Design Range	63x63 alpha Busch-art linear Busch-axcent Busch-axcent pur Busch-balance SI Busch-Duro 2000 Busch-Duro 2000 SI Linear Busch-Dynasty carat future future linear impuls Pure Stainless Steel Reflex SI Reflex SI Linear Reflex SI/SI Linear solo
--------------	---

Material Compliance

Dane RoHS	2CKA200000E0240
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Deklaracja REACH	2CKA309999E9999
REACH Information	True - contains substances > 0.1 mass percentage
Szablon raportowania CMRT	9AKK108468A3363
SCIP	84c471f9-8358-4704-9dd4-decd440a0180 Niemcy (DE)

Wymiary

Szerokość netto	71 mm
Wysokość netto	71 mm
Głębokość / długość netto	42 mm
Masa netto	96.5 g
Głębokość zabudowy (t_2)	32 mm
Rozmiar ekranu	1.68 in

Certyfikaty i deklaracje (Numer dokumentu)

Deklaracja zgodności UE	2CKA100000E0144
-------------------------	-----------------

Klasyfikacje

ETIM 9	EC001588 - Electronic switch
eClass	V11.0 : 27144054
Kategoria WEEE	5. Small Equipment (No External Dimension More Than 50 cm)

Wszelkie prawa zastrzeżone

2024/04/05

Zastrzega się możliwość zmian bez powiadomienia

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA006430A0285	Cover plate with legend Symbols "play, up, down, ok" for Time switch white - Busch-Duro 2000	6435-212	1	sztuka
2CKA006430A0401	Electronic Controls Various symbols for Time switch alpine white - Reflex SI/SI Linear	6435-214-500	1	sztuka
2CKA006430A0450	Cover plate with legend Symbols "play, up, down, ok" for Time switch studio white - Busch-art linear	6435-44G	1	sztuka
2CKA006430A0451	Cover plate with legend Symbols "play, up, down, ok" for Time switch Central cover plate studio white matt - Busch-art linear	6435-44M	1	sztuka
2CKA006430A0453	Cover plate with legend Symbols "play, up, down, ok" for Time switch black matt - Busch-art linear	6435-45M	1	sztuka
2CKA006430A0351	Cover plate with legend Various symbols for Time switch Central cover plate grey metallic - 63x63	6435-803	1	sztuka
2CKA006430A0303	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate anthracite - 63x63	6435-81	1	sztuka
2CKA006430A0304	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate ivory white - 63x63	6435-82	1	sztuka
2CKA006430A0305	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate aluminium silver - 63x63	6435-83	1	sztuka
2CKA006430A0306	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white - 63x63	6435-84	1	sztuka
2CKA006430A0344	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate stainless steel - Pure Stainless Steel	6435-866	1	sztuka
2CKA006430A0388	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate studio white matt - 63x63	6435-884	1	sztuka
2CKA006430A0389	Cover plate with legend Symbol "arrows" and "ok" for Time switch Central cover plate black matt - 63x63	6435-885	1	sztuka
2CKA006430A0353	Electronic Controls Various symbols for Time switch Central cover plate white - Basic55	6435-92-507	1	sztuka
2CKA006430A0352	Electronic Controls Various symbols for Time switch Central cover plate alpine white - Basic55	6435-94-507	1	sztuka
2CKA006430A0393	Electronic Controls Various symbols for Time switch Central cover plate château-black - Basic55	6435-95-507	1	sztuka
2CKA006430A0291	Cover plate with legend Symbols "play, up, down, ok" for Time switch platinum - alpha	6435-20	1	sztuka
2CKA006430A0292	Cover plate with legend Symbols "play, up, down, ok" for Time switch bronze - alpha	6435-21	1	sztuka
2CKA006430A0293	Cover plate with legend Symbols "play, up, down, ok" for Time switch ivory - alpha	6435-22G	1	sztuka
2CKA006430A0295	Cover plate with legend Symbols "play, up, down, ok" for Time switch studio white - alpha	6435-24G	1	sztuka
2CKA006430A0289	Cover plate with legend Symbols "play, up, down, ok" for Time switch palladium - alpha	6435-260	1	sztuka
2CKA006430A0290	Cover plate with legend Symbols "play, up, down, ok" for Time switch titanium - alpha	6435-266	1	sztuka
2CKA006430A0300	Cover plate with legend Symbols "play, up, down, ok" for Time switch alpine white - impuls	6435-74	1	sztuka
2CKA006430A0380	Cover plate with legend Symbols "play, up, down, ok" for Time switch studio white matt - impuls	6435-774	1	sztuka
2CKA006430A0382	Cover plate with legend Symbols "play, up, down, ok" for Time switch black matt - impuls	6435-775	1	sztuka
2CKA006430A0342	Cover plate with legend Symbols "play, up, down, ok" for Time switch aluminium silver - impuls	6435-783	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Flush Mounted Inserts → Electronic Inserts

