

Installation Guide

- Philips CorePro LED HPI lamps

Please take the time to read this installation guide. The guide contains important information and notes regarding the installation and operation.

IMPORTANT!

- · Always switch off the power supply before commencing work!
- The LED lamp is suitable for direct main voltage input.
- ·The LED lamp is NOT compatible with dimmers.
- The LED lamp is NOT compatible to use with ballast.
- · Suitable for use in operating temperature range between -20°C to +45°C.
- · If LED lamp is being use within luminaire, the minimum dimensions requirement on lamp compartment is (HxØ) 400mmx310mm. if the luminaire comes with a glass/cover, it's recommended to detach it for optimal light efficiency and product lifetime. Please check the Tc temperature in application guide for best performance.
- Do not change the structure or any components of the LED lamp to ensure safety.
- The LED lamp is designed to fit in standard IEC compliant E40 lamp holders.
- The LED lamp should be installed by qualified professional electrician.
- · Perform inspection before installation to ensure the luminaire/lamp holder is in good condition to carry the weight and performance of the LED lamp.
- The LED lamps should be positioned so that prolonged staring into the luminaire at a distance closer than Im is not expected.
- · The LED lamp fulfilled IP20 requirement.
- The LED lamp is designed for general lighting service.
- · Please do not apply the LED lamp in applications which contains emergency or/and explosive proof luminaires.
- ·The total system performance may vary depending on the lighting/luminaire system.
- · For latest information, please refer to www.philips.com/lighting
- · In case of doubt, please consult Signify representative.

DISCLAIMER:


Signify disclaims liability for any direct, indirect or incidental damages in case of installation performed either not according to this guide or not performed by a professional electrician.





IP20





For replacing MH HID lamp, convert to mains voltage input












4_b





Perform a visual inspection to ensure the lamp-holder and internal wiring is not damaged, if the lamp-holder is damaged, corroded, charred, blackened, or loose, the lamp holder should be replaced with new lamp-holder. if the internal wire is damaged, it should be replaced with new wire.

- 1) Switch off the power to luminaire.
- 2) Remove diffuser/glass (if provided) and existing lamp from the luminaire.
- 3) Bypass the gear including ballast/capacitor/ignitor and connect lamp-holder wires directly to AC supply leads. Use only on 110-240VAC, 50/60 Hz circuits.
- 4) Check the socket condition (replace it if the condition is poor) then screw in Philips TrueForce LED lamp into the E40 lamp holder firmly.
- 5) Affix the sticker provided inside the luminaire where it is prominently visible to the future installers. The sticker serves to notify that the luminaire has been modified and do not accept traditional HID lamps any longer.
- 6) Switch on power.

59/60Nz	Lamp not suitable for EM ballast operation
	Dimming not allowed
	Lamp not suitable for use under dust and moisture
	Please inform yourself about the local waste disposal, separation and collection system for electrical and electronic products and packaging. Please act according to your local rules and do not dispose your old product and packaging with your normal household waste. The correct disposal of the packaging, your product and/or batteries will help prevent potential negative consequences for the environment and human health. Batteries should be disposed separately from the municipal waste stream via designated collection facilities. When disposing a product that contains non-user replaceable batteries, the non-user replaceable batteries shall be removed by a professional.





All rights reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner. The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent or other industrial or intellectual property rights. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license