

# Specific accessories

## Short circuit plates



**SCB/6/PO/2** Cat. No. **SB203**  
Short circuit plate for two adjacent SCB.6 terminal blocks



**SCB/6/PO/4** Cat. No. **SB204**  
Short circuit plate for four adjacent SCB.6 terminal blocks



**HSCB/6/PO/2** Cat. No. **HB203**  
Short circuit plate for two adjacent HSCB.6 terminal blocks




**HSCB/6/PO/4** Cat. No. **HB204**  
Short circuit plate for four adjacent HSCB.6 terminal blocks



**SCB/4/PO/2** Cat. No. **SB303**  
Short circuit plate for two adjacent SCB.4 terminal blocks



**SCB/4/PO/4** Cat. No. **SB304**  
Short circuit plate for four adjacent SCB.4 terminal blocks



**SCX/PO/2** Cat. No. **SC103**  
Short circuit plate for two adjacent SCX.10 terminal blocks



**SCX/PO/4** Cat. No. **SC104**  
Short circuit plate for four adjacent SCX.10 terminal blocks

Allow the simultaneous earth connection of current transformers already connected to SCB.4, SCB.6 or SCX.10 terminal blocks.  
They are made up of special plates and sleeves guaranteeing the correct operational sequence.  
The plates, in the open position, avoid the translation movement of slide-links, preventing the disconnection of current circuits.

## Short circuit screws and sleeves



**SCB/6/CPM** Cat. No. **SB205**  
Sleeve to be used with SCB/6/PO link



**HSCB/6/CPM** Cat. No. **HB205**  
Sleeve to be used with HSCB/6/PO link



**SCB/4/CPM** Cat. No. **SB305**  
Sleeve to be used with SCB/4/PO link



**SCX/CPM** Cat. No. **SC105**  
Sleeve to be used with SCX/PO link (\*)

(\*) supplied assembled as in position A. In order to be inserted into the slot of the plate, it must be dismounted as in position B, then reassembled and screwed into the body of the terminal block.


## Internal/external cross-connection devices




**FVS/VCI** Cat. No. **FV107**  
Screw and sleeve to perform the internal link between the front and back conducting bodies of FVS.4 terminal block.



**FVS/VCE** Cat. No. **FV108**  
Screw and sleeve to perform the internal and external link between the front and back conducting bodies of FVS.4 terminal blocks.



**DAS/VCI**  
internal cross-connection



**DAS/VCE**  
internal + adjoining front-cross connection

**DAS/VCI** Cat. No. **DS107**  
Screw and sleeve to perform the internal link between the front and back conducting bodies of DAS.4 terminal blocks.

**DAS/VCE** Cat. No. **DS108**  
Screw and sleeve to perform the internal link between front and back conducting bodies or to externally link the conducting bodies of adjacent terminal blocks, of DAS.4 terminal blocks.

## Conducting elements



**CO/5** Cat. No. **VL103**  
Ø 5 x 20 mm - in brass for terminal block types:  
SFO.4 - SFR.4 - SFR.6/M - FLD.10/F5 - HMF.4 - VLM.10



**SFC/CO** Cat. No. **FC102**  
Ø 6,3 x 32 mm - in brass for terminal block types:  
FPC.10 - SFC.10 - SFR.6 - with the option of inserting an SDD/2 test plug

Terminal blocks suited for Ø 5 x 20 mm or Ø 6 x 32 mm fuses can be used as simple disconnection blocks by inserting special **conducting elements**.

## Screening lug



**CBD/SH** Cat. No. **CB009**  
For the connection of the cable shielding - to be used on terminal blocks type CBD.2, 4, 6, 10.